

HUSKY **WeatherBEATER™** **Custom Vehicle Floor Protection**

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater™ Floor Liner from Winfield Consumer Products. Your new front floor liners are custom molded to fit your Scion FR-S and Subaru BRZ. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR YOUR SCION FR-S & SUBARU BRZ FRONT FLOOR LINERS



LEFT OR DRIVER'S



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR FR-S / BRZ FRONT LINERS, MOVE BOTH FRONT SEATS TO THEIR MOST REARWARD POSITION. INSTALL THE LINERS MAKING SURE THEY FASTENED IN PLACE USING THE TWIST-LOCK RETAINERS LOCATED IN THE FACTORY CARPETING. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE FRONT SEATS AS DESIRED.

AS BOXED, THE DRIVER'S SIDE LINER COVERS THE FUEL LEVER RELEASE. THIS AREA IS LOWERED IN THE PART AND CAN EASILY BE REMOVED USING A UTILITY KNIFE. YOU CAN ALSO JUST LIFT THE LINER TO RELEASE THE LEVER AND KEEP THE AREA COVERED.