



# WEATHERBEATER™ FLOOR LINERS

PT #2550

## CARE AND USE INSTRUCTIONS

---

Thank you for selecting a WeatherBeater™ Cargo Liner from Husky Liners. Your new cargo liner is custom molded to fit your Toyota RAV4 (non-Hybrid). Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this “relaxing” may take longer; moving the liner to a heated area will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Do not use Armor All®, Son-of-a-Gun® or similar items as these products make the liner slick.

## CARGO LINER INSTALLATION INSTRUCTIONS FOR YOUR TOYOTA RAV4 (NON-HYBRID MODELS)

