

Thank you for selecting a WeatherBeaterTM Cargo Liner from Winfield Consumer Products. Your new cargo liner is custom molded to fit your Volvo XC90. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this "relaxing" may take longer; moving the liner to a heated area will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409[®] or Glass Plus[®] work well. Do not use Armor All[®], Son-of-a-Gun[®] or similar items as these products make the liner slick.

CARGO LINER INSTALLATION INSTRUCTIONS FOR YOUR VOLVO XC90 (LINER FITS TO BACK OF 2ND ROW SEATS)



FOLD YOUR 3RD ROW SEATS FLAT BEFORE INSTALLING THE CARGO LINER. YOUR LINER IS DESIGNED TO ALLOW ACCESS TO THE FACTORY CARGO TIE-DOWN HOOKS WHEN INSTALLED. TO ACCESS THE HOOKS, TRIM THE MATERIAL AWAY FROM THE LOWERED AREAS IN FRONT OF THE HOOKS. A UTILITY KNIFE WORKS WELL FOR TRIMMING.