

## FORD EDGE FRONT MUD GUARD INSTALLATION INSTRUCTIONS.

*Please read instructions thoroughly before installation.*

### Tools Required

- Flat Blade Screwdriver
- Phillips Head Screwdriver

### Package Contents

- Driver & passenger side front mud guard
- Instruction sheet
- #10 SEM Screws (Qty 6)
- U-Clip (Qty 6)

**NOTE:** Turn the front wheels all the way to the left or right for mud guard installation. However, it may be necessary to remove the wheels depending on the tools being used for installation.

Clean and degrease the mud guard location area on the fender before installation.

1. Remove existing fasteners from location A, B, C and D. Discard all factory fasteners **EXCEPT** location D
2. Pull the factory plastic cladding down and pull inner fender away to access the metal tabs behind the inner fender.
3. Install the supplied U-clips over the existing holes in the metal tab at locations A, B and C.
4. Replace the inner fender and factory cladding back to its original location and re-install the factory fastener at location D.
5. Install mud guard with the supplied #10 SEM screws at locations A, B and C. Check fit and parallel and adjust accordingly before tightening.

