

## SignPast – Care and Use

SignPast signs are made from heavy-duty 18 gauge steel with a baked enamel finish.

For years of enjoyment, we recommend the following to best care for your sign:

- Install/display your signs indoors (all signs and neon signs are designed to be installed indoors)
- Clean enamel signs with a damp, clean, lint-free, soft cloth. An ammonia-free window glass cleaner may be used if the enamel sign becomes very dirty.
- For neon glass tubes: Turn off power and unplug power cord from wall and let neon glass tubes cool. Neon glass tubes are fragile and should be cleaned with extra caution to avoid personal injury or breakage. Clean with an ammonia-free window glass cleaner applied sparingly to a clean, lint-free, soft cloth. Allow cleaner to totally evaporate (tubes should be completely dry) before plugging in power cord and lighting the sign.
- For additional protection of baked enamel signs only – we recommend the application of a high quality automotive wax to the face of the sign. Follow the directions provided by the wax manufacturer.

Installing any SignPast sign (with or without neon) outdoors voids any type of warranty expressed or implied.